





Product use

1. Open the lid then add water (don't exceed the maxwater line), then add 1-3 drops of essential oils.
2. Cover the lid then connect power, start working

Accidental leaks

In the event of accidental leakage during use, proceed as follows.

1. Switch off the power supply, unplug the power cord and open the top cover of the product.
2. Pour out the remaining water from the drain side of the tank completely.
3. Gently shake the body to let the water inside the body drain out through the drainage outlet and leave it in a safe position for 24 hours to dry naturally before continuing to use the product.

Product Care

For every 5-6 uses or 3-5 days, clean the product as follows.

1. Switch off the power supply, unplug the power cord and open the top cover.
2. Pour out the remaining water from the drain side of the tank.
3. Dilute a small amount of kitchen detergent in warm water and then wipe the product with a cloth.
4. If you find dirt on the inside of the air supply opening, please remove the container cover and clean it again (as shown on the right).
5. Do not use medical thinner phenethyl alcohol and neutral detergent when maintaining the product, as this may damage the product or erase the various labels on the product.

Cautions

- The upper limit for use of this product is 12hours. After prolonged use, it should be turned off for a period of time before opening for use to avoid damage to the internal equipment.
- Pay attention to the concentration of the spray, if there is a slight variation in the spray it is normal. Different types of water, temperature, air temperature and wind will have an effect on the product's misting effect.
- It cannot be used without water in the water tank. If there is no water in the water tank, the product will automatically switch on the shutdown protection system, then it is only necessary to refill the water and turn the machine on again to continue using it.
- This product is for use with 100% natural essential oils only, if the essential oil used contains chemicals this may cause damage to the product. When replacing an essential oil with another one, please clean the product first according to the product care instructions.
- Do not dismantle or repair this product by non-technical personnel. For repairs, please contact the sales office of this product.
- After each use, empty the water from the tank completely from the drain side and wipe clean with a rag.
- Aromatherapy oils may cause staining of the product surface. In case of accidental spillage, wipe up immediately with a cloth.
- Do not direct spray at furniture and appliances such as TVs, speaker equipment, clothing, walls, curtains, etc.
- Do not use rags, paper towels or other things to cover the mist outlet of the product to avoid water accumulating in the body and rendering it unusable.
- When using this product, please place it on a flat surface and do not place it on unstable areas such as carpets or sofas.
- Do not place the product in direct sunlight, high temperatures, etc.